



SLAT SHOWER ROOF INSTALLATION INSTRUCTIONS

1. Center the aluminum angle in between the 2 posts. Screw in one end at the desired height using the supplied 2 1/2" screws.



2. Place a level on the aluminum angle. Making sure the piece is leveled, screw the other end into the opposite post using the supplied 2 1/2" screws. Repeat for the second aluminum angle on the posts opposite the first.



3. Screw in the first 2x2 Slat 2 1/4" from the end of the aluminum angle using the 1 5/8" screws on both ends.





SLAT SHOWER ROOF INSTALLATION INSTRUCTIONS

4. Screw in the next 2x2 Slat using the supplied spacer as a guide. Through the pre-drilled guide holes, use 1 5/8" screws to secure both ends.



Spacer

5. Continue with the rest of the 2x2 Slats until you reach the other end.



Congratulations!

Celebrate your new slat roof with a shower!