WOCADIRECT
(877) 962 2645 info@wocadirect.com

WOCA Exterior Wood Cleaner

Exterior Wood Cleaner is for the cleaning of wood decking, fences, doors, carports etc. The product removes green growth and dirt. Decking Cleaner is also very suitable for the cleaning of brickwork and concrete. The cleaner does not impact on vegetation.

Exterior Wood Cleaner is available in 1 and 2.5 liter containers.

Tools
Medium hard nylon brush, plastic bucket, and a garden hose for rinsing.

Consumption
+/- 60 - 100 s.f. / liter

How to do…

1 Soak the wood with plenty of water. If possible use a garden hose.

2 Mix Exterior Cleaner with water in the ratio 1:2 and apply with a stiff brush. By extreme dirt the Wood Cleaner may be used undiluted. Scrub the soaked wood lengthwise of the wood grain until the wood is clean. Repeat the cleaning if necessary. Clean tools in water. Wash carefully with water and remove any loose particles with a stiff brush.

3 The wood must be completely dry before oil treatment. Remove raised fibers with sandpaper.